

RADIATOR FILTER SOCK

For Cars

PWA6337 FITTING INSTRUCTIONS

- Remove top radiator hose
- Push the filter into the top radiator inlet
- Make sure that about 20mm of the filter is protruding and fold back over inlet tube
- Replace hose to inlet making sure that some of the filter is visible
- Observe temp gauge & if heating up clean filter
- After three days of driving remove filter, check and then reuse the same filter
- Check filter regularly
- Replace after 10,000km